


# BTS

BUSINESS TELEPHONE SYSTEMS  
311 West Valley Avenue  
Birmingham, Alabama 35209

NEAX 1000  
Integrated Voice Server



Dterm Series E  
Telephone  
User Guide

### (ALL TRUNKS BUSY)

Dial 9 Dial number; HEAR IMMEDIATE BUSY TONE; Dial 2. When a trunk is available telephone will ring; lift the handset.

### CALL HOLD

1. Depress the **HOLD** Key.

#### To Retrieve:

1. Depress the flashing line key

This call **CANNOT** Be retrieved from any other telephone unless line appearance is set on both telephones.

### CALL TRANSFER

1. With a call in progress depress the **Transfer** key; dial the station number and hang up.

### CALL PARK

1. Depress **Park** Key or Press **Transfer** and dial \*4
2. Read Park location in display (00-19)  
Hang Up
3. Lift handset; Depress Page Key,  
Announce Call Park Location.

#### To Retrieve:

1. Depress **Pick-Up** or dial #4
2. Dial location code

### DIRECTED CALL PICK-UP

Directed: Dial \*2 + extension number

### CONFERENCE

With first call in progress; depress **Transfer**;  
dial second party (outside or inside)  
Depress **CONF** key.

### CALL VOICE MAIL

Press Voice Mail Key or dial voice mail extension.

## CALL FORWARD BNA

### SET:

Dial Call Forward BNA set code \*6  
Dial destination. Hang up

### CANCEL:

Dial cancel code # 6.

## SPEED DIAL

### (1) PROGRAM:

Depress **Feature**; Depress **Redial** dial  
memory ID code (00-19); dial 9 ; dial number to be stored; Depress **Feature**.

### (2) PROGRAM TO A KEY:

Depress **CONF**; Depress key to be programmed; dial 9 ; dial number to be stored;  
Depress **CONF**

## PLACING A SPEED DIAL CALL

(1) Lift handset and/or Depress  
**Redial**; dial memory ID code  
(00-19)

(2) Lift handset and Depress  
Programmed key.

## Last Number Redial

1. Depress **Redial** Key; dial # **or dial \*\***

## Volume Control

### SPEAKER OR HANDSET

1. Lift handset or Depress **Speaker** Key;  
Depress Up/Down Arrow.

### RINGER - While Idle:

1. Depress **Feature** Key; Dial 0 ; Depress  
Up/Down Arrow.

### RINGER - While Ringing:

1. Depress Up/Down Arrow.

## Contrast Control

1. While telephone is Idle; Depress Up/  
Down Arrow

# Quick Reference Feature Codes

Trunk Access	9
Call Voice Mail-	Voice Mail Key
Call Forward BNA - On	*6
Call Forward BNA - Off	#6
Last Number Redial	Redial #
Call Park Set (Location 00-19)	Park or *4
Call Park Retrieve (Location 00-19)	Pick-Up or #4
Call Hold	Hold
Directed Call Pick-Up	*2 + Ext.
Speed Dial (Location 00-19)	Redial
Paging	Page Key
Do Not Disturb Off	DND or *8 DND or #8